

BÂTIS



B3562
9/16" x 3 9/16"
(14 mm x 91 mm)



B4562
9/16" x 4 9/16"
(14 mm x 116 mm)



B4625
5/8" x 4 5/8"
(16 mm x 117 mm)

ARRÊTS



R8750
5/16" x 7/8"
(8 mm x 22 mm)



C1187
5/16" x 1 1/16"
(8 mm x 27 mm)

CADRAGES



R2125
3/8" x 2 1/8"
(8 mm x 54 mm)



C2125
3/8" x 2 1/8"
(10 mm x 54 mm)



C2750
1/2" x 2 3/4"
(13 mm x 70 mm)



C3500
3/4" x 3 1/2"
(19 mm x 89 mm)



Z2250
7/16" x 2 1/4"
(11 mm x 57 mm)



Z2750
7/16" x 2 3/4"
(11 mm x 70 mm)



Z3500
7/16" x 3 1/2"
(11 mm x 89 mm)

PLINTHES




C3125
5/16" x 3 1/8"
(8 mm x 80 mm)



C4125
5/16" x 4 1/8"
(8 mm x 105 mm)



C4250
7/16" x 4 1/4"
(11 mm x 108 mm)



V5500
3/4" x 5 1/2"
(19 mm x 140 mm)



R3125
5/16" x 3 1/8"
(8 mm x 80 mm)



Z4500
7/16" x 4 1/2"
(11 mm x 114 mm)



Z5500
7/16" x 5 1/2"
(11 mm x 140 mm)

MOULURES



R4250
9/16" x 4 1/4"
(14 mm x 108 mm)



R7000
9/16" x 7"
(14 mm x 178 mm)



Z4250
9/16" x 4 1/4"
(14 mm x 108 mm)



D1437
9/16" x 1 7/16"
(14 mm x 37 mm)